

FOREWORD

This service manual has been prepared to provide information covering the wiring diagrams and connector terminal arrangement diagrams for various electric systems mounted on the model J200 series manufactured in November 2007 afterward.

All information used in this service manual was in effect at time when the manual was printed. However, the specifications and procedures may be revised owing to continuing improvements in design without advance notice and without incurring any obligation to us.

Revision 1 : November, 2007

Published in November, 2007

No. 7506

© 2007 DAIHATSU MOTOR CO.,LTD.


All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of Daihatsu Motor Co., LTD.

DAIHATSU MOTOR CO.,LTD.

INDEX

A. GENERAL INFORMATION	A
B. POWER SUPPLY SYSTEM DIAGRAM	B
C. EARTH SYSTEM DIAGRAM	C
D. CIRCUIT DIAGRAM BY FUNCTION	D
E. INDEX	E

NOTE;

The sections denoted by  are not included in this manual. As for those sections for which no entry is made in this manual, see the reference materials posted as the Foreword page. Some changes have been made as to the configuration of this manual, compared with the conventional manual.